TOSHIBA



Stratagy ES Voice Processing System

Quick Reference Guide

Access Stratagy ES

Call Stratagy ES at

Press and enter your Mailbox number.

Enter your security code. (If you make a mistake while entering the code, press to re-enter.)

Stratagy ES plays the number of messages you have and prompts you with Main Menu choices.

MAIN MENU

Play Messages

Send Messages

Manage Mailbox

Retrieve/Listen to E-mail Messages[†]

Exit user mode

Hang up

[†]Plays only if TTS and UM is available

1 PLAY MESSAGES

1 Play the next message

* 1 Replay the current message

Save the current message

Standard Save Message Folder

Personal Message Folder(s)

Play the Previous message Delete the current message

Forward the current message

Reply to the current message Special Functions

Immediate Fax print of all fax

documents within a folder^{††} Immediate Fax print of current fax

document†† Send All Fax documents within a folder

to fax machine for print^{††}

Send Current Fax to fax machine for print^{††}

Message Date and Time

Future Delivery Review Continuous Delete

Access New/Saved message folders (toggle)

Continuous Play

Return to previous menu

Return to Main Menu

2 SEND MESSAGES

Enter destination (one of the following):

Mailbox Number plus #

0 Directory plus name Personal Distribution List (1~25)

4 Multiple Destinations

Record

Record a message, comment or reply (Press # when finished.)

Send and Return to Main Menu

Review recording

Re-record Append recording

Select Additional Destinations

Special Delivery Options

Set Urgent status (On/Off)

Set Private status (On/Off)

Set Return Receipt request (On/Off) 9 Return to previous menu

Set Future Delivery

Cancel message and select new destination

Cancel and Return to Main Menu

3 MANAGE MAILBOX

1 Change Greeting

Change User Options

1 Change Do Not Disturb (On/Off)

2 Change Call Screening (On/Off)

3 Change Security Code

4 Select Busy Greeting (On/Off)

5 Record Busy Greeting

6 Record your Name

7 Change message Notification

8 Set up Automatic Message Copy

Review Option Settings

9 Return to previous menu

Manage Personal Distribution Lists

Manage Guest Mailboxes

Manage Personal Message Folders

Return to Main Menu

Copyright 2004 12/04

CIX-OR-SESR5-VA

††Optional feature

TOSHIBA



Stratagy ES Voice Processing System

Quick Reference Guide

MESSAGE CONTROLS

While playing a message, press:

- 4 Pause/Resume (toggle or 30 secs.)
- 8 Turn Up volume
- Turn Down volume
- Back Up (rewind)
- # Go Forward (advance)
- # Change Speed (toggle)

While recording a message, press:

4 Pause/Resume (toggle or 30 secs.)

4 Retrieve and Listen to E-MAIL MESSAGES^{†††}

- E-MAIL MESSAGESTT

 Listen to e-mail message
- Replay the current e-mail message
- 2 Save the current e-mail message
- 3 Delete the current e-mail message
- Forward the current e-mail message
- 6 Reply to the current e-mail message
- 9 Return to Main Menu (number of e-mail messages to be deleted plays)
 1 Delete e-mail messages
 - 2 Cancel deletion of e-mail messages

MANAGE MAILBOX HINTS

Select a greeting for your mailbox: You can record seven different greetings that can be selected at any time, or choose to use the prerecorded system greeting. Check your greeting frequently to ensure your information is accurate.

Name recording is used for directory information, system greeting, and user identification.

Change your security code on a regular basis.

Record a List Comment to identify/name the list.

MESSAGING HINTS

New Messages play before Saved Messages unless you press **7 7**.

Urgent Messages play first in the New Message Folder.

Private Messages cannot be forwarded.

Immediate Fax transmits fax documents to the fax machine from which you are calling.

Pause/Resume: Press 4 while playing/recording a message to pause (30 seconds); press 4 to resume playing/recording.

To send a **Direct Message** from the Company Greeting, press **9 9 6** or_____ followed by the Mailbox Number.

To send a **Direct Fax** from the Company Greeting, press **9 8 8**. You can record and send a comment with the **Fax document**. When you print the document, the comment does not print.

On/Off options: Each time you press a key with an On/Off option, the features turns On or Off.

Toggle options: Each time that you press a key with a toggle option, the feature switches between the two available settings.

DIRECTORY

^{†††}Requires UM and TTS